



EXAMPLE:
 key down
 P1 - 11² = -15V
 (D1 depressed)

NOTE: Voltage requirements are approximate values.
 X/X= Key up value/Key down value

ALL CONNECTIONS ON THIS PAGE (EXCEPT CONNECTIONS TO THE KEYBOARD) ARE MADE ON PAGE 15.