
POWER SUPPLY
7519601
NOTE: FOR SEMKO SW. CONN. SEE BELOW.
BASS VOICE BD
7217901
SYNTHESIZER BD
7217801
LOWER VOICING BD
7218501
UPPER VOICING BD
7219201
SYNTHESIZER CONTROL BD
7218401
PHASER BD
7218001
SYNTHESIZER SWITCH BD.
7218601
STRING SWITCH BD.
7218301
STRING CONTROL BD
7218201
KEYBOARD
POWER SUPPLY
7520801
POWER SWITCH CONNECTION
SEMKO
ARP
OMNI-2 MODEL 2470
INTERCONNECTION DIAGRAM